

FILETS RAPPORTES HELICOIL®

Ø	Pas	Longueur		Ø Perçage	Référence			
		x d	mm		Free running	SCREWLOCK® Auto-freiné		
M 8	1.25	1 d	8.0	8.4	4130 008 0008	4132 008 0008		
		1.5 d	12.0		4130 008 0012	4132 008 0012		
		2 d	16.0		4130 008 0016	4132 008 0016		
		2.5 d	20.0		4130 008 0020	4132 008 0020		
		3 d	24.0		4130 008 0024	4132 008 0024		
Taraud HC manuel					0140 008 0104			
Taraud HC machine GUN					0141 108 0104			
Taraud HC machine GH					0141 508 0102			
Appareil de pose HC manuel					0150 040 8000			
Broche de pose électrique HC					4160 2508 020	4160 2508 022		
Rupteur mécanique					0158 608 0000			
Extracteur manuel					0180 301 0000			



M 10	1.5	1 d	10.0	10.5	4130 010 0010	4132 010 0010		
		1.5 d	15.0		4130 010 0015	4132 010 0015		
		2 d	20.0		4130 010 0020	4132 010 0020		
		2.5 d	25.0		4130 010 0025	4132 010 0025		
		3 d	30.0		4130 010 0030	4132 010 0030		
Taraud HC manuel					0140 010 0104			
Taraud HC machine GUN					0141 110 0104			
Taraud HC machine GH					0141 510 0102			
Appareil de pose HC manuel					0150 041 0000			
Broche de pose électrique HC					4160 2510 020	4160 2510 022		
Rupteur mécanique					0158 610 0000			
Extracteur manuel					0180 301 0000			



M 12	1.75	1 d	12.0	12.5	4130 012 0012	4132 012 0012		
		1.5 d	18.0		4130 012 0018	4132 012 0018		
		2 d	24.0		4130 012 0024	4132 012 0024		
		2.5 d	30.0		4130 012 0030	4132 012 0030		
		3 d	36.0		4130 012 0036	4132 012 0036		
Taraud HC manuel					0140 012 0104			
Taraud HC machine GUN					0141 112 0104			
Taraud HC machine GH					0141 512 0102			
Appareil de pose HC manuel					0150 041 2000			
Broche de pose électrique HC					4160 2512 020	4160 2512 022		
Rupteur mécanique					0158 612 0000			
Extracteur manuel					0180 302 0000			



Autres dimensions possibles jusqu'au M39 – Nous consulter pour les HELICOIL au pas américain UNC/UNF/BSW/BSF/ GAZ...et coffrets de réparation...